

User guide for the zoom - clarinet barrel

Place the zoom - barrel so on the clarinet, that the zero point and the company logo in a line is the thumb hole!

Turn the collar clockwise until it stops. Above zero appears on the scale of the I.

The intonation adjustment, turn the collar to the left.
Here, the following scales are available: I, II, III, IIII.

In the second rotation, again I, II, III, IIII.

If you turned from position I to position II, the barrel extended by half a millimeter.

A full rotation of the adjustment ring corresponds to an extension of two millimeters.
Two turns correspond to 4mm.

Note:

The barrel extends a maximum of two full turns (4mm), otherwise separate the two parts from each other!